


- 12 keys remote control.
- RF 2.4GHz wireless signal.
- Work with F4-3A/F4-5A/F4-CC wireless drivers to control LED fixtures.
- EX series touch panel optional.



Main Characteristics

Model	F1	F2	F3	F4
Remote Option	Dimming	Color temperature	RGB	RGBW
Working Voltage	3Vdc (Battery CR2032)			
Wireless Frequency	2.4GHz			
Working Temperature	-20 -55			
Dimensions	L145xW40xH12(mm)			
Package Size	L150xW46xH18(mm)			
Weight(G.W.)	85g			

Operating Instruction for Remote

F1

Indicator light

- On/Off
- Brightness-
- Brightness+
- Brightness shortcut key
- Cancel delay off
- Delay off
- Scene keys

Night light mode

F2

Indicator light

- On/Off
- Brightness-
- Brightness+
- CT-/+
- Sunrise
- Sunset
- Delay off
- Daylight
- Night-light
- Scene keys

F3

Indicator light

- On/Off
- Brightness/Speed-
- Brightness/Speed+
- Color-/+
- Red/Green/Blue LED keys
- Saturation
- Scene-mode keys
- Mode

Mode

- Static Red
- Static Green
- Static Blue
- Static Yellow
- Static Purple
- Static Cyan
- Static White
- RGB jumping
- 7 Colors jumping
10. RGB smooth
11. 7 Colors smooth

F4


Indicator light

- On/Off
- Brightness/Speed-
- Brightness/Speed+
- Color-/+
- Red/Green/Blue/White LED keys
- Scene-mode keys
- Mode

Mode


- Static Red
- Static Green
- Static Blue
- Static Yellow
- Static Purple
- Static Cyan
- Static White
- RGB jumping
- 7 Colors jumping
10. RGB smooth
11. 7 Colors smooth
12. Static Black (only turn off RGB)

Wiring Diagram



Dimensions

Unit : mm



F series remote can control wireless driver directly, please refer to the manual of wireless driver for match code method.
 F series remote can work with EX series touch panel, please refer to the manual of touch panel for match code method.

Match/Clear code between remotes

1. Assuming that B match up with A. Short press the bottom two keys of B simultaneously, the indicator light keeps on after release.



2. Then press any key on A in 5 seconds. When the indicator light of B turns off, match successfully.



Clear code

Press the bottom two keys of remote simultaneously (about 10 seconds) until the indicator light keeps on, deactivated the matching successfully.

